



## HUB-LOK™ Suppressor Adapter Installation Guide

**WARNING: BEFORE STARTING, MAKE SURE THE WEAPON IS UNLOADED, THE CHAMBER IS EMPTY, AND THE SAFETY IS ENGAGED.**

### Notes before starting:

- Please read through this entire guide before starting installation.
- If you have any questions, please contact [info@quiet-labs.com](mailto:info@quiet-labs.com).
- If you are uncomfortable performing installation, we recommend using a qualified gunsmith.

### What you will need for this installation:

- Quiet Labs HUB-LOK™ Adapter
- Suppressor with HUB (1.375x24) threads
- Plan-B compatible muzzle device installed on host firearm
- Optional: Rocksett (for suppressor-to-adapter installation)

### Installation Steps:

#### 1 Remove cage from adapter

Using the included driver, remove the six screws and separate the cage from the HUB-LOK adapter.

#### 2 Install suppressor onto HUB-LOK adapter

Thread the suppressor onto the adapter and torque to the suppressor manufacturer's recommended specification. Do not exceed 25 ft-lbs. Rocksett is optional.

#### 3 Install cage/shroud over suppressor

Slide the cage/shroud over the suppressor and align the six mounting holes with the threaded holes in the adapter.

#### 4 Install and torque cage screws

Install the six included screws and torque each screw to 12–15 in-lbs. Tighten evenly in a cross pattern.

## **5 Install assembly onto muzzle device**

Thread the complete HUB-LOK and suppressor assembly onto the Plan-B compatible muzzle device.

### **Additional Notes:**

- All HUB-LOK adapters are QC checked before packaging.
- We strongly recommend checking suppressor alignment on every host firearm.
- The adapter and cage are designed to remain mounted to the suppressor for repeatable performance.
- Periodically check suppressor that it is tight on muzzle device when safe and cool to touch.