



POD-MOD X4 Installation instructions

Tools & parts

- Arca-Lock clamp (or Arca-Lock + Picatinny adapter for two-screw models)
- Allen key (included with Arca-Lock clamp)
- Your Atlas bipod (QD-lever model or two-screw model)

A. For Atlas bipods with the QD lever (one-to-one swap)

- Ensure rifle is unloaded and bipod is removed or stable to work on.
- Locate the two screws on top of the QD/Picatinny clamp.
- Use the included Allen key to fully remove those two screws.
- Lift the QD/Picatinny clamp straight off.



- Place the Arca-Lock clamp into the same position (it's a 1:1 replacement).
- Reinstall the same two screws and tighten with the Allen key.
- Check that the Arca-Lock clamp is secure and the bipod locks properly into Arca rails.

B&T bipods torque to 20-25 In-Lbs

Total of 4 screws (2 included, 2 original from existing bipod/clamp)